§ 149.316

complement of persons and equipment, at a rate of not less than 59 feet per minute.

(i) The operator may use an onboard crane to launch a rescue boat if the crane's launching system meets the requirements of this section.

§ 149.316 What are the requirements for lifejackets?

- (a) Each lifejacket must be approved under approval series 160.002, 160.005, 160.055, 160.077, or 160.176.
- (b) Each lifejacket must have a light approved under approval series 161.012. Each light must be securely attached to the front shoulder area of the lifejacket.
- (c) Each lifejacket must have a whistle permanently attached by a cord.
- (d) Each lifejacket must be fitted with Type I retroreflective material, approved under approval series 164.018.

§149.317 How and where must lifejackets be stowed?

- (a) The operator must ensure that lifejackets are stowed in readily accessible places in or adjacent to accommodation spaces.
- (b) Lifejacket stowage containers and the spaces housing the containers must not be capable of being locked.
- (c) The operator must mark each life-jacket container or lifejacket stowage location with the word "LIFE-JACKETS" in block letters, and the quantity, identity, and size of the lifejackets stowed inside the container or at the location.

§ 149.318 Must every person on the port have a lifejacket?

The operator must provide a life-jacket that complies with \$149.316 of this subpart for each person on a manned deepwater port.

§ 149.319 What additional lifejackets must I have?

For each person on duty in a location where the lifejacket required by §149.317 of this subpart is not readily accessible, an additional lifejacket must be stowed so as to be readily accessible to that location.

§149.320 What are the requirements for ring life buoys?

- (a) Ring life buoys must be approved under approval series 160.050 or 160.150, for SOLAS-approved equipment.
- (b) Each ring life buoy must have a floating electric water light approved under approval series 161.010. The operator must ensure that the light to the ring life buoy is attached by a lanyard of 12-thread manila, or a synthetic rope of equivalent strength, not less than 3 feet nor more than 6 feet in length. The light must be mounted on a bracket near the ring life buoy so that, when the ring life buoy is cast loose, the light will be pulled free of the bracket.
- (c) To each ring life buoy, there must be attached a buoyant line of 100 feet in length, with a breaking strength of at least 5 kilonewtons force. The end of the line must not be secured to the deepwater port.
- (d) Each ring life buoy must be marked with Type II retroreflective material, approved under approval series 164 018

§ 149.321 How many ring life buoys must be on each deepwater port?

There must be at least four approved ring life buoys on each manned deepwater port.

§ 149.322 Where must ring life buoys be located and how must they be stowed?

- (a) The operator must locate one ring life buoy on each side of the port and one near each external stairway leading to the water. One buoy per side may be used to satisfy both these requirements.
- (b) Each ring life buoy must be stowed on or in a rack that is readily accessible in an emergency. The ring life buoy must not be permanently secured in any way to the rack or the deepwater port.

§ 149.323 What are the requirements for first aid kits?

(a) Each manned deepwater port must have an industrial first aid kit, approved by an appropriate organization, such as the American Red Cross, for the maximum number of persons on the deepwater port.